

UNEW PART LIST

Capital, major and consumable spare parts for the Siemens SGT5-2000E / V94.2 (Si3D) gas turbine, with installation location on the machine

This list covers the capital, major and consumable spare parts manufactured and supplied by UNEW, Inc. for the Siemens SGT5-2000E / V94.2 (Si3D) gas turbine engine class. It is issued by UNEW, Inc. as the designer and manufacturer of the listed parts.

The column headed Installation Location on the Machine and Drawing Reference states, for each item, the assembly of the gas turbine on which the part is installed, the position within that assembly, and the drawing on which the item appears. Drawing references are given on two bases. Where the item corresponds to an item on the original equipment manufacturer assembly drawing for the machine, that drawing title and item number are quoted and are marked OEM drawing. Where the item is manufactured to a UNEW drawing, the UNEW drawing title and drawing item location number are quoted and are marked UNEW drawing. Every item in this list is located on the machine without exception.

Total items listed: 265. Part numbers, PB numbers and drawing item location numbers in the first four columns are UNEW numbers assigned by UNEW, Inc. as the designer and manufacturer of the supplied parts. Item numbers marked OEM drawing in the fifth column are original equipment manufacturer drawing item numbers and are given for position reference only.

Where two part numbers are shown for one line item as Type 1 and Type 2, the applicable type is confirmed by UNEW, Inc. against the as-built configuration and the serial number of the unit before manufacture.

Date: 10 August 2026

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
1	A2A50021940-G001	PB0000251001	MBCSN10.0101	Installed on the turbine stator carrier (vane carrier), turbine vane row 1, upper and lower halves. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0101.	Standard Turbine Vane Segment, Row 1. High-temperature cobalt-base superalloy (FSX-414) vane segment used in the turbine vane ring. Features complex internal cooling passages, film cooling holes, and MCrAlY overlay coating.
2	A2A50021941-G002	PB0000251002	MBCSN90.0002	Installed on the turbine stator carrier (vane carrier), turbine vane row 1, upper and lower halves, horizontal casing split-line joint/lead position. UNEW drawing "Turbine Stator", Item No.: MBCSN90.0002.	Joint/Lead Vane Segment, Row 1. Specialized vane segment positioned directly at the horizontal casing joint split line. Features modified outer shroud platforms to ensure a flush, high-pressure seal across the casing split.
3	A2A50021942-G003	PB0000251003	MBCSN90.0003	Installed on the turbine stator carrier (vane carrier), turbine vane row 1, upper and lower halves, designated instrumented/thermocouple or transition-interface position. UNEW drawing "Turbine Stator", Item No.: MBCSN90.0003.	Instrumented/Transition Vane Segment, Row 1. Specialized segment adjacent to the silo combustor transition pieces and may include passages to accommodate localized hot-gas telemetry/thermocouple instrumentation.
4	A2A50024312-G001	PB0000251004	MBCSN10.0204	Installed on the turbine stator carrier (vane carrier), turbine vane row 2, upper and lower halves. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0204.	Standard Turbine Vane Segment, Row 2. Cast double-vane (twin) cobalt-base superalloy (FSX-414) segment. Features internal convective cooling paths supplied via the stator blade carrier and MCrAlY overlay coating.
5	A2A50024312-G002	PB0000251005	MBCSN90.0005	Installed on the turbine stator carrier (vane carrier), turbine vane row 2, upper and lower halves, horizontal casing split-line joint/lead position. UNEW drawing "Turbine Stator", Item No.: MBCSN90.0005.	Joint Vane Segment, Row 2. Specialized twin-vane segment positioned at the horizontal casing split line. Features modified outer and inner platforms to ensure sealing continuity at the joint.
6	A2A50024312-G003	PB0000251006	MBCSN10.0206	Installed on the turbine stator carrier (vane carrier), turbine vane row 2, upper and lower halves, designated instrumented/thermocouple or transition-interface position. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0206.	Instrumented Turbine Vane Segment, Row 2. Standard Row 2 twin-vane profile modified with precision-machined guide holes through the platform and airfoil to house thermocouple probes for interstage gas temperature tracking.
7	A2A5116244-G001	PB0000251007	MBCSN10.0307	Installed on the turbine stator carrier (vane carrier), turbine vane row 3, upper and lower halves. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0307.	Standard Turbine Vane Segment, Row 3. Large low-pressure multi-airfoil cobalt-base superalloy (FSX-414) cast segment. Optimized Si3D aerodynamic profile with reduced cooling duty in the Si3D configuration of this unit.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
8	A2A5116244-G002	PB0000251008	MBCSN90.0008	Installed on the turbine stator carrier (vane carrier), turbine vane row 3, upper and lower halves, horizontal casing split-line joint/lead position. UNEW drawing "Turbine Stator", Item No.: MBCSN90.0008.	Joint Vane Segment, Row 3. Specialized segment located at the horizontal casing split line. Features modified outer and inner platform margins to form a flush, tight seal across the turbine blade carrier joint.
9	A2A5116244-G003	PB0000251009	MBCSN10.0309	Installed on the turbine stator carrier (vane carrier), turbine vane row 3, upper and lower halves, designated instrumented/thermocouple or transition-interface position. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0309.	Instrumented Turbine Vane Segment, Row 3. Multi-airfoil profile modified with dedicated instrumentation ports and through-holes to guide temperature sensors into the interstage flow path.
10	A2A5118611-G001	PB0000251010	MBCSN10.0410	Installed on the turbine stator carrier (vane carrier), turbine vane row 4, upper and lower halves. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0410.	Standard Turbine Vane Segment, Row 4. Massive low-pressure, uncooled multi-airfoil cobalt-base superalloy (FSX-414) cast segment. Engineered for high mechanical rigidity and optimal flow alignment into the exhaust diffuser.
11	A2A5118611-G002	PB0000251011	MBCSN90.0011	Installed on the turbine stator carrier (vane carrier), turbine vane row 4, upper and lower halves, horizontal casing split-line joint/lead position. UNEW drawing "Turbine Stator", Item No.: MBCSN90.0011.	Joint Vane Segment, Row 4. Specialized exhaust stage segment positioned at the horizontal casing split line, featuring modified platform profiles to match the turbine blade carrier joint.
12	A2A5118611-G003	PB0000251012	MBCSN10.0412	Installed on the turbine stator carrier (vane carrier), turbine vane row 4, upper and lower halves, designated instrumented/thermocouple or transition-interface position. UNEW drawing "Turbine Stator", Item No.: MBCSN10.0412.	Instrumented Turbine Vane Segment, Row 4. Vane segment modified with precision through-holes to accommodate the exhaust gas temperature (EGT) thermocouple matrix probes.
13	A2A50012458-G001	PB0000252001	MBCSN11.0113	Installed on the turbine wheel row 1, blade root slots of the turbine disc. UNEW drawing "Turbine wheel 1", Item No.: MBCSN11.0113.	Standard Turbine Blade, Row 1. High-temperature nickel-base superalloy, Si3D optimized profile. Features advanced internal convective and film cooling channels with leading-edge gill holes and a fir-tree root configuration.
14	A2A50012458-G002	PB0000252002	MBCSN11.0114	Installed on the turbine wheel row 1, blade root slots of the turbine disc, final closing and locking blade positions. UNEW drawing "Turbine wheel 1", Item No.: MBCSN11.0114.	Locking Turbine Blade, Row 1. Matches standard Row 1 airfoil geometry for aerodynamic balance. Modified root platform machined to accept locking keys/pins to secure the entire stage circumferentially.
15	A2A50012458-G003	PB0000252003	MBCSN90.0015	Installed on the turbine wheel row 1, blade root slots of the turbine disc, balance-assigned blade positions per the moment-weight distribution. UNEW drawing "Turbine wheel 1", Item No.: MBCSN90.0015.	Weighted / Balanced Segment Blade, Row 1. Airfoil structurally identical to the standard blade, but selected or grouped by moment weight for rotor balance control to minimize rotor unbalance.
16	A2A50014822-G001	PB0000252004	MBCSN11.0216	Installed on the turbine wheel row 2, blade root slots of the turbine disc. UNEW drawing "Turbine wheel 2", Item No.: MBCSN11.0216.	Standard Turbine Blade, Row 2. Mid-pressure stage airfoil featuring internal radial cooling passages and advanced thermal barrier coating (TBC). Designed with a fir-tree root for axial insertion.
17	A2A50014822-G002	PB0000252005	MBCSN11.0217	Installed on the turbine wheel row 2, blade root slots of the turbine disc, final closing and locking blade positions. UNEW drawing "Turbine wheel 2", Item No.: MBCSN11.0217.	Locking Turbine Blade, Row 2. Identical profile to the standard blade, featuring a modified root platform machined to receive the final locking plates/pins that secure the continuous ring.
18	A2A50014822-G003	PB0000252006	MBCSN90.0018	Installed on the turbine wheel row 2, blade root slots of the turbine disc, balance-assigned blade positions per the moment-weight distribution. UNEW drawing "Turbine wheel 2", Item No.: MBCSN90.0018.	Weighted / Balanced Segment Blade, Row 2. Structurally identical airfoil profile, factory-sorted and classified by precise moment-weight deviations (or modified for balance weights) to ensure vibration-free rotor operation.
19	A2A50113110-G001	PB0000252007	MBCSN11.0319	Installed on the turbine wheel row 3, blade root slots of the turbine disc. UNEW drawing "Turbine wheel 3", Item No.: MBCSN11.0319.	Standard Turbine Blade, Row 3. Large low-pressure stage blade in nickel-base superalloy (IN738LC), featuring an optimized Si3D aerodynamic profile and interlocking tip shrouds, at reduced cooling duty in the Si3D configuration of this unit.
20	A2A50113110-G002	PB0000252008	MBCSN11.0320	Installed on the turbine wheel row 3, blade root slots of the turbine disc, final closing and locking blade positions. UNEW drawing "Turbine wheel 3", Item No.: MBCSN11.0320.	Locking Turbine Blade, Row 3. Identical airfoil and tip shroud profile, but with a modified root platform designed to accommodate the final closing key mechanism for the Row 3 disc.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
21	A2A50113110-G003	PB0000252009	MBCSN90.0021	Installed on the turbine wheel row 3, blade root slots of the turbine disc, balance-assigned blade positions per the moment-weight distribution. UNEW drawing "Turbine wheel 3", Item No.: MBCSN90.0021.	Weighted / Balanced Segment Blade, Row 3. Airfoil structurally identical to the standard blade, factory-classified by strict momentweight parameters to ensure precise balancing across the rotor assembly.
22	A2A50113110-G004	PB0000252010	MBCSN11.0422	Installed on the turbine wheel row 4, blade root slots of the turbine disc. UNEW drawing "Turbine wheel 4", Item No.: MBCSN11.0422.	Standard Turbine Blade, Row 4. Massive exhaust stage moving blade. Uncooled solid airfoil body designed for maximum kinetic energy extraction, featuring large interlocking tip shrouds.
23	A2A50113110-G005	PB0000252011	MBCSN11.0423	Installed on the turbine wheel row 4, blade root slots of the turbine disc, final master/closing and locking blade positions. UNEW drawing "Turbine wheel 4", Item No.: MBCSN11.0423.	Locking Blades (Master Blades / Closing Blades) , Row 4, integrated slots to accommodate the final locking pin, screw, or piece. They act as the "keys" to close the row and keep all standard blades mechanically secured under the extreme centrifugal loads of 3,000 RPM operation.
24	A2A2001101-G001	PB0000253001	MBCSN22.0123	Installed on the compressor rotor, compressor blade row 1 (stage 1). UNEW drawing item No.: MBCSN22.0123.	Standard Compressor Blade, Row 1. Large Ti-6Al-4V (Grade 5) titanium alloy blade, shot peened. Inlet stage designed for high mass flow. Features a wide chord and a machined dovetail root.
25	A2A2001101-G002	PB0000253002	MBCSN22.0124	Installed on the compressor rotor, compressor blade row 1 (stage 1), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0124.	Locking Compressor Blade, Row 1. Row 1 blade with a modified base configuration designed to receive the final row-locking key or pin hardware.
26	A2A2001102-G001	PB0000253003	MBCSN22.0225	Installed on the compressor rotor, compressor blade row 2 (stage 2). UNEW drawing item No.: MBCSN22.0225.	Standard Compressor Blade, Row 2. Front-stage compression blade. Heavy-duty construction to handle initial pressure rise and centrifugal loads.
27	A2A2001102-G002	PB0000253004	MBCSN22.0226	Installed on the compressor rotor, compressor blade row 2 (stage 2), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0226.	Locking Compressor Blade, Row 2. Row 2 blade with root platform modification for locking piece insertion.
28	A2A2001103-G001	PB0000253005	MBCSN22.0327	Installed on the compressor rotor, compressor blade row 3 (stage 3). UNEW drawing item No.: MBCSN22.0327.	Standard Compressor Blade, Row 3. Front-stage blade featuring a slightly reduced chord length compared to Row 2, optimized for subsonic flow conditioning.
29	A2A2001103-G002	PB0000253006	MBCSN22.0328	Installed on the compressor rotor, compressor blade row 3 (stage 3), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0328.	Locking Compressor Blade, Row 3. Row 3 blade modified at the root platform to secure the stage assembly.
30	A2A2001104-G001	PB0000253007	MBCSN22.0429	Installed on the compressor rotor, compressor blade row 4 (stage 4). UNEW drawing item No.: MBCSN22.0429.	Standard Compressor Blade, Row 4. Transition front-stage blade. High fatigue resistance profile designed to manage aerodynamic loading.
31	A2A2001104-G002	PB0000253008	MBCSN22.0430	Installed on the compressor rotor, compressor blade row 4 (stage 4), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0430.	Locking Compressor Blade, Row 4. Row 4 blade with specialized base machining for closing hardware.
32	A2A2001105-G001	PB0000253009	MBCSN22.0531	Installed on the compressor rotor, compressor blade row 5 (stage 5). UNEW drawing item No.: MBCSN22.0531.	Standard Compressor Blade, Row 5. Final stage of the frontcompressor section before intermediate matching. Machined dovetail root configuration.
33	A2A2001105-G002	PB0000253010	MBCSN22.0532	Installed on the compressor rotor, compressor blade row 5 (stage 5), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0532.	Locking Compressor Blade, Row 5. Row 5 closing blade featuring specialized root locking slot geometry.
34	A2A2001106-G001	PB0000253011	MBCSN22.0633	Installed on the compressor rotor, compressor blade row 6 (stage 6). UNEW drawing item No.: MBCSN22.0633.	Standard Compressor Blade, Row 6. Middle-stage compression blade. The airfoil cross-section becomes noticeably thinner as the air volume decreases.
35	A2A2001106-G002	PB0000253012	MBCSN22.0634	Installed on the compressor rotor, compressor blade row 6 (stage 6), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0634.	Locking Compressor Blade, Row 6. Row 6 blade with root platform machined to receive circumferential locking pins.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
36	A2A2001107-G001	PB0000253013	MBCSN22.0735	Installed on the compressor rotor, compressor blade row 7 (stage 7). UNEW drawing item No.: MBCSN22.0735.	Standard Compressor Blade, Row 7. Middle-stage blade optimized for high efficiency under increasing pressure gradients.
37	A2A2001107-G002	PB0000253014	MBCSN22.0736	Installed on the compressor rotor, compressor blade row 7 (stage 7), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0736.	Locking Compressor Blade, Row 7. Row 7 closing blade with modified platform for locking piece integration.
38	A2A2001108-G001	PB0000253015	MBCSN22.0837	Installed on the compressor rotor, compressor blade row 8 (stage 8). UNEW drawing item No.: MBCSN22.0837.	Standard Compressor Blade, Row 8. Middle-stage blade. Airfoil height continues to scale down progressively.
39	A2A2001108-G002	PB0000253016	MBCSN22.0838	Installed on the compressor rotor, compressor blade row 8 (stage 8), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0838.	Locking Compressor Blade, Row 8. Row 8 blade featuring locking hardware accommodation on the base.
40	A2A2001109-G001	PB0000253017	MBCSN22.0939	Installed on the compressor rotor, compressor blade row 9 (stage 9). UNEW drawing item No.: MBCSN22.0939.	Standard Compressor Blade, Row 9. Middle-stage blade. Highstrength steel designed to resist high-cycle fatigue from flow variations.
41	A2A2001109-G002	PB0000253018	MBCSN22.0940	Installed on the compressor rotor, compressor blade row 9 (stage 9), final closing/locking blade position. UNEW drawing item No.: MBCSN22.0940.	Locking Compressor Blade, Row 9. Row 9 blade with modified root to secure the stage circumferentially.
42	A2A2001110-G001	PB0000253019	MBCSN22.1041	Installed on the compressor rotor, compressor blade row 10 (stage 10). UNEW drawing item No.: MBCSN22.1041.	Standard Compressor Blade, Row 10. Transition blade moving into the high-pressure compressor zone.
43	A2A2001110-G002	PB0000253020	MBCSN22.1042	Installed on the compressor rotor, compressor blade row 10 (stage 10), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1042.	Locking Compressor Blade, Row 10. Row 10 closing blade featuring specialized locking slot layout.
44	A2A2001111-G001	PB0000253021	MBCSN22.1143	Installed on the compressor rotor, compressor blade row 11 (stage 11). UNEW drawing item No.: MBCSN22.1143.	Standard Compressor Blade, Row 11. High-pressure stage blade. Compact, rigid airfoil geometry to withstand dense, highly compressed air.
45	A2A2001111-G002	PB0000253022	MBCSN22.1144	Installed on the compressor rotor, compressor blade row 11 (stage 11), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1144.	Locking Compressor Blade, Row 11. Row 11 blade with base modified for locking key retention.
46	A2A2001112-G001	PB0000253023	MBCSN22.1245	Installed on the compressor rotor, compressor blade row 12 (stage 12). UNEW drawing item No.: MBCSN22.1245.	Standard Compressor Blade, Row 12. High-pressure stage blade. Reduced span height, designed for high mechanical rigidity.
47	A2A2001112-G002	PB0000253024	MBCSN22.1246	Installed on the compressor rotor, compressor blade row 12 (stage 12), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1246.	Locking Compressor Blade, Row 12. Row 12 closing blade with modified root platform geometry.
48	A2A2001113-G001	PB0000253025	MBCSN22.1347	Installed on the compressor rotor, compressor blade row 13 (stage 13). UNEW drawing item No.: MBCSN22.1347.	Standard Compressor Blade, Row 13. High-pressure stage blade. Profile optimized for minimized boundary layer losses.
49	A2A2001113-G002	PB0000253026	MBCSN22.1348	Installed on the compressor rotor, compressor blade row 13 (stage 13), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1348.	Locking Compressor Blade, Row 13. Row 13 blade with root modifications to house closing hardware.
50	A2A2001114-G001	PB0000253027	MBCSN22.1449	Installed on the compressor rotor, compressor blade row 14 (stage 14). UNEW drawing item No.: MBCSN22.1449.	Standard Compressor Blade, Row 14. Rear high-pressure stage blade. Short, highly rigid airfoil profile.
51	A2A2001114-G002	PB0000253028	MBCSN22.1450	Installed on the compressor rotor, compressor blade row 14 (stage 14), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1450.	Locking Compressor Blade, Row 14. Row 14 closing blade with specialized base machining.
52	A2A2001115-G001	PB0000253029	MBCSN22.1551	Installed on the compressor rotor, compressor blade row 15 (stage 15). UNEW drawing item No.: MBCSN22.1551.	Standard Compressor Blade, Row 15. Penultimate compressor stage blade. Subjected to high operating temperatures due to intense air compression.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
53	A2A2001115-G002	PB0000253030	MBCSN22.1552	Installed on the compressor rotor, compressor blade row 15 (stage 15), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1552.	Locking Compressor Blade, Row 15. Row 15 closing blade with specialized root platform locking keys.
54	A2A2001116-G001	PB0000253031	MBCSN22.1653	Installed on the compressor rotor, compressor blade row 16 (stage 16). UNEW drawing item No.: MBCSN22.1653.	Standard Compressor Blade, Row 16. Final discharge stage compressor blade. Very short profile, engineered to push high-pressure air directly into the diffuser and combustor shell casing.
55	A2A2001116-G002	PB0000253032	MBCSN22.1654	Installed on the compressor rotor, compressor blade row 16 (stage 16), final closing/locking blade position. UNEW drawing item No.: MBCSN22.1654.	Locking Compressor Blade, Row 16. Final Row 16 closing blade featuring root platform modification to complete the entire rotor assembly ring.
56	A2A50330309	PB0000330309	MBCSN11.0155	Installed on the turbine wheel row 1, blade shank heat shield position, at the blade platform/wheel-rim gas-path interface. UNEW drawing "Turbine wheel 1", Item No.: MBCSN11.0155.	Heat Shield - Turbine Blade Row 1. Installed at the blade platform / wheel-rim gas-path interface to shield the wheel rim from the hot gas path and to maintain the gas-path boundary at the blade shank.
57	A2A50330310	PB0000330310	MBCSN11.0256	Installed on the turbine wheel row 2, blade shank heat shield position, at the blade platform/wheel-rim gas-path interface. UNEW drawing "Turbine wheel 2", Item No.: MBCSN11.0256.	Heat Shield - Turbine Blade Row 2. Installed at the blade platform / wheel-rim gas-path interface to shield the wheel rim from the hot gas path and to maintain the gas-path boundary at the blade shank.
58	A2A50320208 (Type 1) / A2A50320209 (Type 2)	PB0000320208 / PB0000320209	MBCSN20.0007	Installed on the compressor inlet casing, variable inlet guide vane ring at the compressor inlet. UNEW drawing item No.: MBCSN20.0007.	Compressor Inlet Guide Vane. Compressor inlet guide vane assembly used to control inlet air angle and compressor operating margin during start-up, part-load and full-load operation.
59	A2A50320210	PB0000320210	MBCSN90.0058	Installed on the compressor diffuser at the compressor discharge, in the diffuser/stator-vane carrier between the final compressor stage and the combustion casing. UNEW drawing item No.: MBCSN90.0058.	Compressor Diffuser Vane. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
60	A2A50233554	PB0000233554	MBCSN11.0004	Installed on the compressor casing, compressor stator 1, stationary blade ring of compressor stage 1. OEM drawing "COMPRESSOR STATOR 1", Item No.: MBCSN11.0004.	Compressor Stationary Blade Ring Stage 1. Stationary compressor airfoil for stage 1 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
61	A2A50202879	PB0000202879	MBCSN11.0005	Installed on the compressor casing, compressor stator 1, stationary blade row of compressor stage 2. OEM drawing "COMPRESSOR STATOR 1", Item No.: MBCSN11.0005.	Compressor Stationary Blade Stage 2. Stationary compressor airfoil for stage 2 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
62	A2A50233556	PB0000233556	MBCSN11.0006	Installed on the compressor casing, compressor stator 1, stationary blade row of compressor stage 3. OEM drawing "COMPRESSOR STATOR 1", Item No.: MBCSN11.0006.	Compressor Stationary Blade Stage 3. Stationary compressor airfoil for stage 3 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
63	A2A50006885	PB0000006885	MBCSN21.0003	Installed on the compressor casing, compressor stator 2, stationary blade row of compressor stage 5. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0003.	Compressor Stationary Blade Stage 5. Stationary compressor airfoil for stage 5 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
64	A2A50006886	PB0000006886	MBCSN21.0004	Installed on the compressor casing, compressor stator 2, stationary blade row of compressor stage 6. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0004.	Compressor Stationary Blade Stage 6. Stationary compressor airfoil for stage 6 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
65	A2A50006887	PB0000006887	MBCSN21.0005	Installed on the compressor casing, compressor stator 2, stationary blade row of compressor stage 7. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0005.	Compressor Stationary Blade Stage 7. Stationary compressor airfoil for stage 7 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
66	A2A50006889	PB0000006889	MBCSN21.0007	Installed on the compressor casing, compressor stator 2, stationary blade row of compressor stage 9. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0007.	Compressor Stationary Blade Stage 9. Stationary compressor airfoil for stage 9 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
67	A2A50006890	PB0000006890	MBCSN31.0003	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 10. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0003.	Compressor Stationary Blade Stage 10. Stationary compressor airfoil for stage 10 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
68	A2A50006891	PB0000006891	MBCSN31.0004	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 11. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0004.	Compressor Stationary Blade Stage 11. Stationary compressor airfoil for stage 11 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
69	A2A50006892	PB0000006892	MBCSN31.0005	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 12. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0005.	Compressor Stationary Blade Stage 12. Stationary compressor airfoil for stage 12 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
70	A2A50006893	PB0000006893	MBCSN31.0006	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 13. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0006.	Compressor Stationary Blade Stage 13. Stationary compressor airfoil for stage 13 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
71	A2A50006894	PB0000006894	MBCSN31.0007	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 14. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0007.	Compressor Stationary Blade Stage 14. Stationary compressor airfoil for stage 14 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
72	A2A50006895	PB0000006895	MBCSN31.0008	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 15. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0008.	Compressor Stationary Blade Stage 15. Stationary compressor airfoil for stage 15 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
73	A2A50006896	PB0000006896	MBCSN31.0009	Installed on the compressor casing, compressor stator 3, stationary blade row of compressor stage 16. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0009.	Compressor Stationary Blade Stage 16. Stationary compressor airfoil for stage 16 of the sixteen stage compressor. Guides and diffuses the compressor airflow between the rotating blade rows and maintains the aerodynamic efficiency and the casing clearance of the stage.
74	A2A50271494	PB0000271494	MBCSN05.0059	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0002.	Fuel Oil Burner (Complete). Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
75	A2A50139461	PB0000139461	MBCSN05.0060	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.	Burner Assembly. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
76	A2A50249155	PB0000249155	MBCSN05.0061	Installed on the combustion chamber, burner insert ring position of the burner belt. OEM drawing "Combustion chamber Shop assembly", Item No.: MBCBP06.0008.0005.	Burner Insert Ring. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
77	A2A50000463	PB0000000463	MBCSN05.0062	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0001.0030.	Swirler for Fuel Gas Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
78	A2A50000003	PB0000000003	MBCSN05.0063	Installed on the combustion chamber, burner insert ring position of the burner belt. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0012.0006.	Insert Ring - Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
79	A2A50006762	PB0000006762	MBCSN05.0064	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0002.0004.	Nozzle Complete - Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
80	A2A50006625	PB0000006625	MBCSN05.0065	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0002.0003.	Return Line Complete - Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
81	A2A50000055	PB0000000055	MBCSN05.0066	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0012.0005.	Union Nut / Cap Nut - Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
82	A2A50268329	PB0000268329	MBCSN05.0067	Installed on the hybrid burner assembly of combustion chambers A and B. UNEW drawing "BURNER ASSEMBLY", Item No.: MBCSN05.0067.	Cap - Fuel Oil Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
83	A2A50286314	PB0000286314	MBCSN05.0068	Installed on the hybrid burner assembly of combustion chambers A and B. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0002.0009.	Seal Ring - Burner. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
84	A2A50000462	PB0000000462	MBCSN90.0069	Installed on the hybrid burner assembly of combustion chambers A and B, ignition device position. OEM drawing "BURNER ASSEMBLY", Item No.: MBCBB00.0012.0002.	Ignition Electrode. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
85	A2A50006506	PB0000006506	MBCSN05.0070	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0008.0015.	Bolt - Combustion Chamber. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
86	A2A50244819	PB0000244819	MBCSN05.0071	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0002.0008.	Brick A1/A2 - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
87	A2A50244819	PB0000244819	MBCSN05.0072	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. UNEW drawing "Combustion chamber shop assembly", Item No.: MBCSN05.0072.	Brick F - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
88	A2A50005764	PB0000005764	MBCSN05.0073	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0008.0008.	Cotter Pin - Combustion Chamber. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
89	A2A50014634	PB0000014634	MBCSN05.0074	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. UNEW drawing "Combustion chamber shop assembly", Item No.: MBCSN05.0074.	Covering - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
90	A2A50230302	PB0000230302	MBCSN90.0075	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0101.0002.0002.	Fitting Piece Shim. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
91	A2A50008135	PB0000008135	MBCSN05.0076	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0008.0024.	Hexagon Cap Screw - Combustion Chamber. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
92	A2A50018298	PB0000018298	MBCSN05.0077	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0008.0023.	Holder - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
93	A2A50000432	PB0000000432	MBCSN05.0078	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0002.0052.	Lock - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
94	A2A50107670	PB0000107670	MBCSN05.0079	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0011.	Manhole Insert - Combustor. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
95	A2A50016759	PB0000016759	MBCSN05.0080	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, SHOP ASSEMBLY", Item No.: MBCBP06.0006.0101.0002.0004.	Parallel Pin - Combustion Chamber. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
96	A2A50005861	PB0000005861	MBCSN05.0081	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0009.0024.	Plate - Combustion Chamber. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
97	A2A50000944	PB0000000944	MBCSN05.0082	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER, FIELD ASSEMBLY", Item No.: MBCBP00.0096.0007.	Seal Ring - Combustion Chamber Field Assembly. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
98	A2A50226484	PB0000226484	MBCSN90.0083	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0002.0035.	Tile Holder F Lower. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
99	A2A50226483	PB0000226483	MBCSN90.0084	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions. OEM drawing "COMBUSTION CHAMBER", Item No.: MBCBP05.0002.0034.	Tile Holder F Upper. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
100	A2A50006431	PB0000006431	MBCSN90.0085	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0094.	Pilot Valve Complete. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
101	A2A50006583	PB0000006583	MBCSN90.0086	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0026.	Pilot Valve. Replacement component for the applicable V94.2 / SGT52000E gas turbine assembly.
102	A2A50006429	PB0000006429	MBCSN05.0087	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0006.	Piston (Fuel Gas Equipment). Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
103	A2A50006441	PB0000006441	MBCSN90.0088	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0081.	Piston (Electro Hydraulic Converter). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
104	A2A50005707 (Type 1) / A2A50006462 (Type 2)	PB0000005707 (Type 1) / PB0000006462 (Type 2)	MBCSN90.0089	Installed on the fuel gas equipment unit of the gas fuel supply system, in the valve actuator as the piston-to-stem connecting rod. UNEW drawing "Equipment unit, fuel gas", Item No.: MBCSN90.0089.	Piston Rod. Replacement component for the applicable V94.2 / SGT52000E gas turbine assembly.
105	A2A50006607	PB0000006607	MBCSN70.0090	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0070.	Control Sleeve Complete. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
106	A2A50006422	PB0000006422	MBCSN90.0091	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0006.	Stem. Replacement component for the applicable V94.2 / SGT52000E gas turbine assembly.
107	A2A50006328	PB0000006328	MBCSN05.0092	Installed on the fuel oil stop valve of the liquid fuel supply system. OEM drawing "fuel oil stop valve", Item No.: MBMBV2X.0006.	Valve Stem Complete - Fuel Oil Stop Valve. Combustion and fuelsystem component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
108	A2A50005761 (Type 1) / A2A50005760 (Type 2)	PB0000005761 (Type 1) / PB0000005760 (Type 2)	MBCSN90.0093	Installed on the fuel gas equipment unit of the gas fuel supply system, in the valve body as the stem/spool guide bushing. UNEW drawing "Equipment unit, fuel gas", Item No.: MBCSN90.0093.	Valve Bushing Complete. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
109	A2A50006426	PB0000006426	MBCSN90.0094	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0037.	Tension Spring Complete. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
110	A2A50005665	PB0000005665	MBCSN90.0095	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0034.	Compression Spring (Type 1). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
111	A2A50005666	PB0000005666	MBCSN90.0096	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0036.	Compression Spring (Type 2). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
112	A2A50005667	PB0000005667	MBCSN90.0097	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0035.	Compression Spring (Type 3). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
113	A2A50005693	PB0000005693	MBCSN90.0098	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0010.	Compression Spring (Type 4). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
114	A2A50005694	PB0000005694	MBCSN90.0099	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0011.	Compression Spring (Type 5). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
115	A2A50005843 (Type 1) / A2A50005844 (Type 2)	PB0000005843 (Type 1) / PB0000005844 (Type 2)	MBCSN05.0100	Installed on the fuel oil stop valve of the liquid fuel supply system. OEM drawing "fuel oil stop valve", Item No.: MBMBV2X.0018.	Compression Spring - Fuel Oil Stop Valve. Combustion and fuelsystem component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
116	A2A50005809	PB0000005809	MBCSN30.0101	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0077.	Ball Thrust Bearing 51100. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
117	A2A50006607	PB0000006607	MBCSN30.0102	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0070.	Ball Thrust Bearing - Control Sleeve. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
118	A2A50006748 (Type 1) / A2A50006597 (Type 2)	PB0000006748 (Type 1) / PB0000006597 (Type 2)	MBCSN90.0103	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0022.	Sliding Block. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
119	A2A50006459	PB0000006459	MBCSN90.0104	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0082.	Bushing (Electro Hydraulic Converter). Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
120	A2A50006454	PB0000006454	MBCSN05.0105	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0007.	Bushing (Fuel Gas Equipment). Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
121	A2A50001049	PB0000001049	MBCSN40.0106	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0002.0008.	Diaphragm Seal. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
122	A2A50006699	PB0000006699	MBCSN90.0107	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0010.	Feedback Cone. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
123	A2A50000338	PB0000000338	MBCSN40.0108	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0002.0036.	Floating Ring Seal. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
124	A2A50006404	PB0000006404	MBCSN40.0109	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0036.	Gasket (Type 1). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
125	A2A50006405	PB0000006405	MBCSN40.0110	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0037.	Gasket (Type 2). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
126	A2A50006409	PB0000006409	MBCSN40.0111	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0039.	Gasket (Type 3). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
127	A2A50006501	PB0000006501	MBCSN40.0112	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0038.	Gasket (Type 4). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
128	A2A50006408	PB0000006408	MBCSN40.0113	Installed on the fuel oil control valve of the liquid fuel supply system. UNEW drawing "fuel oil control valve", Item No.: MBCSN40.0113.	Gasket 0.5mm. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
129	A2A50000209	PB0000000209	MBCSN40.0114	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0052.	O-Ring Ø64x3mm. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
130	A2A50015448	PB0000015448	MBCSN50.0115	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0109.	Bolt (Electro Hydraulic Converter). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
131	A2A50015271	PB0000015271	MBCSN50.0116	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0001.0031.	Cap Nut. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
132	A2A50014477	PB0000014477	MBCSN50.0117	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0061.	Slotted Nut M12. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
133	A2A50015242	PB0000015242	MBCSN05.0118	Installed on the fuel oil stop valve of the liquid fuel supply system. OEM drawing "fuel oil stop valve", Item No.: MBMBV2X.0030.	Threaded Bolt - Fuel Oil Stop Valve. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
134	A2A50000201	PB0000000201	MBCSN50.0119	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0003.0070.	Cotter Pin 2x25. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
135	A2A50005744	PB0000005744	MBCSN50.0120	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0060.	Cotter Pin (Electro Hydraulic Converter). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
136	A2A50006422 (Type 1) / A2A50005688 (Type 2)	PB0000006422 (Type 1) / PB0000005688 (Type 2)	MBCSN50.0121	Installed on the electro hydraulic converter of the fuel control system. OEM drawing "Electro Hydraulic Converter", Item No.: MBMBS03.0137.	Taper Pin. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
137	A2A50005845	PB0000005845	MBCSN05.0122	Installed on the fuel gas equipment unit of the gas fuel supply system. OEM drawing "Equipment unit, fuel gas", Item No.: MBMBP4Y.0002.0059.	Taper Pin (Fuel Gas Equipment). Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
138	A2A50014483	PB0000014483	MBCSN50.0123	Installed on the electro hydraulic converter of the fuel control system. UNEW drawing "Electro Hydraulic Converter", Item No.: MBCSN50.0123.	Parallel Pin 3m6x8. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
139	A2A50346416	PB0000346416	MBCSN90.0124	Installed on the electro hydraulic converter of the fuel control system. UNEW drawing "Electro Hydraulic Converter", Item No.: MBCSN90.0124.	Moving Coil. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
140	A2A50350508	PB0000350508	MBCSN05.0125	Installed on the fuel gas equipment unit of the gas fuel supply system, on the fuel-gas valve/control manifold. UNEW drawing "Equipment unit, fuel gas", Item No.: MBCSN05.0125.	Solenoid Valve - Fuel Gas Control. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
141	A2A50310101 (Type 1) / A2A50310102 (Type 2)	PB0000310101 (Type 1) / PB0000310102 (Type 2)	MBCSN30.0126	Installed on the turbine bearing casing at the turbine end of the rotor, around the turbine shaft front journal. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN30.0126.	Journal Bearing - Turbine Front. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
142	A2A50310103	PB0000310103	MBCSN30.0127	Installed on the turbine bearing casing at the turbine end of the rotor, around the turbine shaft rear journal. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN30.0127.	Journal Bearing - Turbine Rear. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
143	A2A50310104 (Type 1) / A2A50310105 (Type 2)	PB0000310104 (Type 1) / PB0000310105 (Type 2)	MBCSN30.0128	Installed on the turbine bearing casing at the turbine end of the rotor, in the active/inactive thrust-pad carrier around the thrust collar. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN30.0128.	Thrust Bearing Pad. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
144	A2A50310106 (Type 1) / A2A50310107 (Type 2)	PB0000310106 (Type 1) / PB0000310107 (Type 2)	MBCSN30.0129	Installed on the bearing casings of the gas turbine, compressor end and turbine end, at the shaft penetration to retain oil and limit air leakage. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN30.0129.	Bearing Housing Seal Ring. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
145	A2A50310108 (Type 1) / A2A50310109 (Type 2)	PB0000310108 (Type 1) / PB0000310109 (Type 2)	MBCSN90.0130	Installed on the bearing casings of the gas turbine, compressor end and turbine end, around the shaft as the oil-deflector interface. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN90.0130.	Oil Deflector Ring. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
146	A2A50310110	PB0000310110	MBCSN40.0131	Installed on the compressor bearing casing at the compressor end of the rotor, around the rotor shaft at the compressor inlet end. UNEW drawing "Bearing Casing, compressor", Item No.: MBCSN40.0131.	Labyrinth Seal - Compressor Front. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
147	A2A50006589	PB0000006589	MBCSN30.0132	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0014.	Bearing Block (Type 1). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
148	A2A50006590	PB0000006590	MBCSN30.0133	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0015.	Bearing Block (Type 2). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
149	A2A50006591	PB0000006591	MBCSN30.0134	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0016.	Bearing Block (Type 3). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
150	A2A50006592	PB0000006592	MBCSN30.0135	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0017.	Bearing Block (Type 4). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
151	A2A50000105	PB0000000105	MBCSN30.0136	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "Bearing Casing, Turbine", Item No.: MBCSL11.0002.0007.	Disk - Turbine Bearing Casing. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
152	A2A50799800	PB0000799800	MBCSN60.0137	Installed on the turbine bearing casing, lube oil hose connection. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN60.0137.	Hose Line Complete Ø55mm (1230x55x25mm). Piping or flow component used to route cooling air, oil, fuel or service fluid to the applicable turbine system.
153	A2A50354342	PB0000354342	MBCSN30.0138	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0005.0003.	Hose Line Complete - Compressor Bearing. Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
154	A2A50062127	PB0000062127	MBCSN50.0139	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0024.	Locking Pin. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
155	A2A50006702	PB0000006702	MBCSN50.0140	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0018.	Notched Pin. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
156	A2A50000070	PB0000000070	MBCSN30.0141	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "Bearing Casing, Turbine", Item No.: MBCSL11.0002.0006.	Seal Ring - Turbine Bearing Casing. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
157	A2A50005603	PB0000005603	MBCSN30.0142	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0006.	Seal Strip - Compressor Bearing Casing. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
158	A2A50006604	PB0000006604	MBCSN90.0143	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0013.	Spring Element. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.
159	A2A50000013	PB0000000013	MBCSN30.0144	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "INSTRUMENTATION TURBINE BEARING", Item No.: MBBGH20.0111.	Seal Ring - Turbine Bearing Instrumentation. Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
160	A2A50005644	PB0000005644	MBCSN30.0145	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "Bearing Casing, Turbine", Item No.: MBCSL11.0006.0001.0002.0007.	Taper Pin - Turbine Bearing Casing (Type 1). Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
161	A2A50005670	PB0000005670	MBCSN30.0146	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "Bearing Casing, Turbine", Item No.: MBCSL11.0001.0021.	Taper Pin - Turbine Bearing Casing (Type 2). Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
162	A2A50008530	PB0000008530	MBCSN30.0147	Installed on the turbine bearing casing at the turbine end of the rotor. OEM drawing "Bearing Casing, Turbine", Item No.: MBCSL11.0005.0010.	Taper Pin - Turbine Bearing Casing (Type 3). Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
163	A2A50000087	PB0000000087	MBCSN30.0148	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "BEARING CASING COMPRESSOR, ASSEMBLY", Item No.: MBCSC00.0029.	Taper Pin - Compressor Bearing Pedestal (Type 1). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
164	A2A50000089	PB0000000089	MBCSN30.0149	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0011.	Taper Pin - Compressor Bearing Casing. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
165	A2A50005806	PB0000005806	MBCSN30.0150	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "BEARING CASING COMPRESSOR, ASSEMBLY", Item No.: MBCSC00.0048.	Taper Pin - Compressor Bearing Pedestal (Type 2). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
166	A2A50006588	PB0000006588	MBCSN30.0151	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "Bearing Casing, compressor", Item No.: MBCSC11.0006.0018.	Taper Pin - Compressor Bearing Casing (Type 2). Bearing or bearingsupport component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
167	A2A50005654	PB0000005654	MBCSN30.0152	Installed on the compressor bearing casing at the compressor end of the rotor. OEM drawing "BEARING CASING COMPRESSOR, ASSEMBLY", Item No.: MBCSC00.0021.	Taper Pin - Compressor Bearing Pedestal (Type 3). Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
168	A2A50006776	PB0000006776	MBCSN40.0153	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.0025.	Seal Ring between IC & Rotor. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
169	A2A50163562	PB0000163562	MBCSN11.0054	Installed on the turbine wheel row 4 of the turbine rotor. OEM drawing "TURBINE WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0002.0021.0011.	Bolt - Turbine Wheel 4 (Type 1). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
170	A2A50006114	PB0000006114	MBCSN11.0055	Installed on the turbine wheel row 1 of the turbine rotor. OEM drawing "TURBINE WHEEL 1, ASSEMBLY", Item No.: MBRTA10.0002.0005.0011.	Bolt - Turbine Wheel 1. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
171	A2A50006531	PB0000006531	MBCSN11.0056	Installed on the turbine wheel row 4 of the turbine rotor. OEM drawing "TURBINE WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0002.0021.0012.	Lock Washer - Turbine Wheel 4. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
172	A2A50005889	PB0000005889	MBCSN11.0057	Installed on the turbine wheel row 4 of the turbine rotor. OEM drawing "TURBINE WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0002.0016.0003.0001.	Parallel Key - Turbine Wheel 4. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
173	A2A50006470	PB0000006470	MBCSN11.0058	Installed on the turbine wheel row 1 of the turbine rotor. OEM drawing "TURBINE WHEEL 1, ASSEMBLY", Item No.: MBRTA10.0002.0005.0003.	Parallel Key - Turbine Wheel 1. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
174	A2A50006480	PB0000006480	MBCSN11.0059	Installed on the turbine wheel row 1 of the turbine rotor. OEM drawing "TURBINE WHEEL 1, ASSEMBLY", Item No.: MBRTA10.0002.0005.0010.	Seal Strip - Turbine Wheel 1. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
175	A2A50006377	PB0000006377	MBCSN11.0060	Installed on the turbine wheel row 2 of the turbine rotor. OEM drawing "TURBINE WHEEL 2, ASSEMBLY", Item No.: MBRTA10.0002.0011.0010.	Seal Strip - Turbine Wheel 2. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
176	A2A50006518 (Type 1) / A2A50006520 (Type 2)	PB0000006518 (Type 1) / PB0000006520 (Type 2)	MBCSN11.0061	Installed on the turbine wheel row 4 of the turbine rotor. OEM drawing "TURBINE WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0002.0016.0010.	Seal Strip - Turbine Wheel 4. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
177	A2A50006476 (Type 1) / A2A50006477 (Type 2)	PB0000006476 (Type 1) / PB0000006477 (Type 2)	MBCSN11.0062	Installed on the turbine wheel row 1 of the turbine rotor. OEM drawing "TURBINE WHEEL 1, ASSEMBLY", Item No.: MBRTA10.0002.0005.0006.	Seal Wire - Turbine Wheel 1. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
178	A2A50309555 (Type 1) / A2A50309547 (Type 2)	PB0000309555 (Type 1) / PB0000309547 (Type 2)	MBCSN11.0063	Installed on the turbine wheel row 2 of the turbine rotor. OEM drawing "TURBINE WHEEL 2, ASSEMBLY", Item No.: MBRTA10.0002.0011.0006.	Seal Wire - Turbine Wheel 2. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
179	A2A50006106	PB0000006106	MBCSN11.0064	Installed on the turbine wheel row 3 of the turbine rotor. OEM drawing "TURBINE WHEEL 3, ASSEMBLY", Item No.: MBRTA10.0002.0016.0005.	Seal Wire - Turbine Wheel 3. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
180	A2A50006107	PB0000006107	MBCSN11.0065	Installed on the turbine wheel row 4 of the turbine rotor. OEM drawing "TURBINE WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0002.0021.0005.	Seal Wire - Turbine Wheel 4. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
181	A2A50005661	PB0000005661	MBCSN11.0066	Installed on the turbine wheel row 1 of the turbine rotor. UNEW drawing "Turbine wheel 1", Item No.: MBCSN11.0066.	Threaded Pin - Turbine Wheel 1. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
182	A2A50006473	PB0000006473	MBCSN11.0067	Installed on the turbine wheel row 3 of the turbine rotor. OEM drawing "TURBINE WHEEL 3, ASSEMBLY", Item No.: MBRTA10.0002.0016.0004.	Threaded Pin - Turbine Wheel 3. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
183	A2A50005738	PB0000005738	MBCSN50.0168	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator assembly", Item No.: MBCSP00.0064.	Hexagon Cap Screw - Turbine Stator Assembly. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
184	A2A50006155	PB0000006155	MBCSN50.0169	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0023.	Lock Washer - Turbine Stator Carrier. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
185	A2A50006481	PB0000006481	MBCSN50.0170	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0006.	Parallel Pin - Turbine Stator Carrier (Type 1). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
186	A2A50006508	PB0000006508	MBCSN50.0171	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0022.0001.	Parallel Pin - Turbine Stator Carrier (Type 2). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
187	A2A50006509	PB0000006509	MBCSN50.0172	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0022.0002.	Parallel Pin - Turbine Stator Carrier (Type 3). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
188	A2A50309751	PB0000309751	MBCSN50.0173	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0010.0001.	Parallel Pin - Turbine Stator Carrier (Type 4). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
189	A2A50309752	PB0000309752	MBCSN50.0174	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0010.0002.	Parallel Pin - Turbine Stator Carrier (Type 5). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
190	A2A50006542	PB0000006542	MBCSN40.0175	Installed on the divided seal ring of the turbine stator carrier. OEM drawing "Turbine Stator", Item No.: MBCSP01.0042.	Parallel Pin - Sealing Divided. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
191	A2A50006468	PB0000006468	MBCSN50.0176	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0013.	Pin - Turbine Stator Carrier (Type 1). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
192	A2A50307606	PB0000307606	MBCSN50.0177	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0093.	Pin - Turbine Stator Carrier (Type 2). Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
193	A2A50694200	PB0000694200	MBCSN40.0178	Installed on the divided seal ring of the turbine stator carrier, at the split seal-ring retaining position. UNEW drawing "Turbine Stator", Item No.: MBCSN40.0178.	Cup Spring Set - Sealing Divided. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
194	A2A50397900	PB0000397900	MBCSN40.0179	Installed on the divided seal ring of the turbine stator carrier, at the split seal-ring retaining position. UNEW drawing "Turbine Stator", Item No.: MBCSN40.0179.	Fixing Pin - Sealing Divided. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
195	A2A50398100	PB0000398100	MBCSN40.0180	Installed on the divided seal ring of the turbine stator carrier, at the split seal-ring retaining position. UNEW drawing "Turbine Stator", Item No.: MBCSN40.0180.	Pin - Sealing Divided (Type 1). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
196	A2A50643800	PB0000643800	MBCSN40.0181	Installed on the divided seal ring of the turbine stator carrier, at the split seal-ring retaining position. UNEW drawing "Turbine Stator", Item No.: MBCSN40.0181.	Pin - Sealing Divided (Type 2). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
197	A2A50398000	PB0000398000	MBCSN40.0182	Installed on the divided seal ring of the turbine stator carrier, at the split seal-ring retaining position. UNEW drawing "Turbine Stator", Item No.: MBCSN40.0182.	Threaded Pin - Sealing Divided. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
198	A2A50000594	PB0000000594	MBCSN50.0183	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0043.	Threaded Pin - Turbine Stator Carrier. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
199	A2A50006486	PB0000006486	MBCSN40.0184	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0015.	Seal Strip - Turbine Stator Carrier (Type 1). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
200	A2A50006488	PB0000006488	MBCSN40.0185	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0020.	Seal Strip - Turbine Stator Carrier (Type 2). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
201	A2A50006491	PB0000006491	MBCSN40.0186	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0016.	Seal Strip - Turbine Stator Carrier (Type 3). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
202	A2A50006524	PB0000006524	MBCSN40.0187	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0018.	Seal Strip - Turbine Stator Carrier (Type 4). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
203	A2A50307703	PB0000307703	MBCSN40.0188	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0004.	Seal Strip - Turbine Stator Carrier (Type 5). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
204	A2A50307704	PB0000307704	MBCSN40.0189	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0005.	Seal Strip - Turbine Stator Carrier (Type 6). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
205	A2A50307605	PB0000307605	MBCSN40.0190	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0028.	Seal Strip - Turbine Stator Carrier (Type 7). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
206	A2A50307697	PB0000307697	MBCSN40.0191	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0008.	Seal Strip - Turbine Stator Carrier (Type 8). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
207	A2A50307698	PB0000307698	MBCSN40.0192	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0090.	Seal Strip - Turbine Stator Carrier (Type 9). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
208	A2A50307701	PB0000307701	MBCSN40.0193	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0091.	Seal Strip - Turbine Stator Carrier (Type 10). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
209	A2A50307700	PB0000307700	MBCSN40.0194	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0092.	Seal Strip - Turbine Stator Carrier (Type 11). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
210	A2A50307699	PB0000307699	MBCSN40.0195	Installed on the turbine stator carrier (vane carrier), horizontal joint and carrier fixing positions. OEM drawing "Turbine Stator", Item No.: MBCSP01.0012.	Seal Strip - Turbine Stator Carrier (Type 12). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
211	A2A50397700 (Type 1) / A2A50397600 (Type 2)	PB0000397700 (Type 1) / PB0000397600 (Type 2)	MBCSN40.0196	Installed on the turbine stator carrier, seal ring position of turbine row 4. OEM drawing "Turbine Stator", Item No.: MBCSP01.0025.	Seal Strip / Seal Ring 4 Turbine. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
212	A2A50006772	PB0000006772	MBCSN90.0197	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. UNEW drawing "Inner casing", Item No.: MBCSN90.0197.	Disk - Inner Casing (Type 1). Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
213	A2A50006777	PB0000006777	MBCSN90.0198	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.0017.	Disk - Inner Casing (Type 2). Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
214	A2A50006778	PB0000006778	MBCSN90.0199	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.0018.	Disk - Inner Casing (Type 3). Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
215	A2A50005729	PB0000005729	MBCSN90.0200	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.0027.	Disk - Inner Casing (Type 4). Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
216	A2A50006773	PB0000006773	MBCSN90.0201	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0002.	Shim - Inner Casing. Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
217	A2A50000757	PB0000000757	MBCSN50.0202	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.	Hexagon Cap Screw - Inner Casing. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
218	A2A50006775	PB0000006775	MBCSN50.0203	Installed on the inner casing of the gas turbine, between the inner casing and the rotor. OEM drawing "Inner casing", Item No.: MBCSR10.0001.0026.	Hexagon Screw - Inner Casing. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
219	A2A50000076	PB0000000076	MBCSN40.0204	Installed on the blow off (anti surge) control rack of the compressor casing. OEM drawing "BLOW-OFF CONTROL RACK", Item No.: MBMBP4Y.0003.0045.	Seal Ring - Blow-Off Control Rack. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
220	A2A50005726	PB0000005726	MBCSN40.0205	Installed at the general sealing positions of the gas turbine casing and pipe joints. UNEW drawing item No.: MBCSN40.0205.	Seal Ring (General). Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
221	A2A50033709	PB0000033709	MBCSN21.0006	Installed on compressor stator 3 of the compressor casing. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0070.	Bolt - Compressor Stator 3. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
222	A2A50006189	PB0000006189	MBCSN21.0007	Installed on compressor stator 1 of the compressor casing. OEM drawing "COMPRESSOR STATOR 1", Item No.: MBCSN11.0018.	Hexagon Cap Screw - Compressor Stator 1. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
223	A2A50001192	PB0000001192	MBCSN21.0008	Installed on compressor stator 2 of the compressor casing. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0020.	Hexagon Cap Screw - Compressor Stator 2. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
224	A2A50006162	PB0000006162	MBCSN21.0009	Installed on compressor stator 2 of the compressor casing. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0024.	Locking Sheet - Compressor Stator 2. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
225	A2A50033711	PB0000033711	MBCSN21.0010	Installed on compressor stator 3 of the compressor casing. OEM drawing "COMPRESSOR STATOR 3", Item No.: MBCSN31.0072.	Round Stock - Compressor Stator 3. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
226	A2A50000395	PB0000000395	MBCSN21.0011	Installed on compressor stator 2 of the compressor casing. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.00061.	Screw Plug - Compressor Stator 2. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
227	A2A50000396	PB0000000396	MBCSN21.0012	Installed on compressor stator 2 of the compressor casing. OEM drawing "COMPRESSOR STATOR 2", Item No.: MBCSN21.0062.	Seal Ring - Compressor Stator 2. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
228	A2A50007403	PB0000007403	MBCSN50.0213	Installed on the compressor rotor, compressor wheel (disc) 1. OEM drawing "COMPRESSOR WHEEL 1, ASSEMBLY", Item No.: MBRTA10.0001.0010.0003.	Lock Washer - Compressor Wheel 1. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
229	A2A50007404	PB0000007404	MBCSN50.0214	Installed on the compressor rotor, compressor wheel (disc) 2. OEM drawing "COMPRESSOR WHEEL 2, ASSEMBLY", Item No.: MBRTA10.0001.0011.0003.	Lock Washer - Compressor Wheel 2. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
230	A2A50007405	PB0000007405	MBCSN50.0215	Installed on the compressor rotor, compressor wheel (disc) 3. OEM drawing "COMPRESSOR WHEEL 3, ASSEMBLY", Item No.: MBRTA10.0001.0012.0003.	Lock Washer - Compressor Wheel 3. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
231	A2A50007406	PB0000007406	MBCSN50.0216	Installed on the compressor rotor, compressor wheel (disc) 4. OEM drawing "COMPRESSOR WHEEL 4, ASSEMBLY", Item No.: MBRTA10.0001.0013.0003.	Lock Washer - Compressor Wheel 4. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
232	A2A50140030	PB0000140030	MBCSN50.0217	Installed on the compressor rotor, compressor wheel (disc) 5. UNEW drawing item No.: MBCSN50.0217.	Lock Washer - Compressor Wheel 5. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
233	A2A50310030	PB0000310030	MBCSN21.0018	Installed on compressor stator 3, stationary blade ring of compressor stage 10. UNEW drawing "COMPRESSOR STATOR 3", Item No.: MBCSN21.0018.	Lock Washer - Compressor Stator Ring 10. Stationary compressor airfoil / stator component for the applicable stage. Used to guide and diffuse compressor airflow between rotating blade stages while maintaining aerodynamic efficiency and casing clearances.
234	A2A50008168	PB0000008168	MBCSN50.0219	Installed on the rotor coupling flange between the gas turbine and the generator. OEM drawing "COMPRESSOR AND GENERATOR, ASSEMBLY", Item No.: MBGNJ00.0003.	Coupling Bolt. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
235	A2A50008169	PB0000008169	MBCSN50.0220	Installed on the rotor coupling flange between the gas turbine and the generator. OEM drawing "COMPRESSOR AND GENERATOR, ASSEMBLY", Item No.: MBGNJ00.0004.	Cap Nut - Coupling. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
236	A2A50015536	PB0000015536	MBCSN90.0221	Installed on the compressor rotor, support cone and spacer positions of the rotor stack. OEM drawing "Rotor", Item No.: MBRTA10.0002.0026.	Damper Ring Stage 4 Support Cone. Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
237	A2A50015536	PB0000015536	MBCSN90.0222	Installed on the compressor rotor, support cone and spacer positions of the rotor stack. OEM drawing "Rotor", Item No.: MBRTA10.0001.0004.	Damper Ring Stage 6 Support Cone. Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
238	A2A50015406	PB0000015406	MBCSN50.0223	Installed on the compressor rotor, support cone and spacer positions of the rotor stack. OEM drawing "Rotor", Item No.: MBRTA10.0001.0005.	Damping Cone Stage 9/12 Support Cone. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
239	A2A50185369	PB0000185369	MBCSN90.0224	Installed on the compressor rotor, support cone and spacer positions of the rotor stack. OEM drawing "Rotor", Item No.: MBRTA10.0001.0008.	Spacer Ring 12. Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
240	A2A50033730	PB0000033730	MBCSN90.0225	Installed on the compressor rotor, support cone and spacer positions of the rotor stack. OEM drawing "Rotor", Item No.: MBRTA10.0002.0027.	Spacer Ring 4. Structural turbine/compressor component used for rotor, stator, casing, spacing, damping or support functions in the applicable assembly.
241	A2A50005647	PB0000005647	MBCSN40.0226	Installed on the shaft seal at the compressor front end of the rotor. OEM drawing "Shaft seal", Item No.: MBCSL27.0005.	Taper Pin - Shaft Seal. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
242	A2A50340401	PB0000340401	MBCSN60.0227	Installed on the turbine cooling air supply piping to turbine vane row 1, between the cooling-air manifold and turbine Row 1. UNEW drawing item No.: MBCSN60.0227.	Cooling Air Pipe - Turbine Row 1. Piping or flow component used to route cooling air, oil, fuel or service fluid to the applicable turbine system.
243	A2A50340402	PB0000340402	MBCSN60.0228	Installed on the turbine cooling air supply piping to turbine vane row 2, between the cooling-air manifold and turbine Row 2. UNEW drawing item No.: MBCSN60.0228.	Cooling Air Pipe - Turbine Row 2. Piping or flow component used to route cooling air, oil, fuel or service fluid to the applicable turbine system.

UNEW PART LIST | SIEMENS SGT5-2000E / V94.2 (Si3D) GAS TURBINE

Document No. UNEW-PL-001, Rev. 01 | UNEW, Inc., 2570 N. First Street, 2nd Floor, San Jose, CA 95131, United States

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
244	A2A50340403	PB0000340403	MBCSN05.0229	Installed on the combustion chamber (silo type chambers A and B), ceramic lining and chamber assembly positions, in the designated cooling-air nozzle or orifice position. UNEW drawing "Combustion chamber shop assembly", Item No.: MBCSN05.0229.	Cooling Air Nozzle Insert. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
245	A2A50340404	PB0000340404	MBCSN30.0230	Installed on the lube oil supply unit, duplex filter housing, inside the lube-oil filter housing. UNEW drawing item No.: MBCSN30.0230.	Filter Element - Lube Oil System. Filtration component used to protect the applicable oil, fuel, hydraulic or air system from contamination.
246	A2A50340405	PB0000340405	MBCSN05.0231	Installed on the fuel gas equipment unit of the gas fuel supply system, inside the fuel-gas filter/strainer housing. UNEW drawing "Equipment unit, fuel gas", Item No.: MBCSN05.0231.	Filter Element - Fuel Gas. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
247	A2A50340406 (Type 1) / A2A50340407 (Type 2)	PB0000340406 (Type 1) / PB0000340407 (Type 2)	MBCSN60.0232	Installed on the hydraulic oil supply unit of the gas turbine, inside the hydraulic-oil filter housing. UNEW drawing item No.: MBCSN60.0232.	Filter Element - Hydraulic Oil. Filtration component used to protect the applicable oil, fuel, hydraulic or air system from contamination.
248	A2A50340408	PB0000340408	MBCSN05.0233	Installed on the fuel gas equipment unit of the gas fuel supply system, in the coalescing-filter vessel upstream of the fuel-gas control equipment. UNEW drawing "Equipment unit, fuel gas", Item No.: MBCSN05.0233.	Coalescing Filter - Fuel Gas System. Combustion and fuel-system component used for fuel delivery, fuel-air mixing, ignition stability or combustion hardware sealing in the V94.2 / SGT5-2000E combustion system.
249	A2A50340409	PB0000340409	MBCSN40.0234	Installed on the lube oil supply unit, duplex filter housing, at the filtercover/flange sealing interface. UNEW drawing item No.: MBCSN40.0234.	Duplex Filter Housing Gasket. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
250	A2A50340410	PB0000340410	MBCSN60.0235	Installed on the accessory gearbox of the gas turbine auxiliary drive, at the gearbox breather/vent connection. UNEW drawing item No.: MBCSN60.0235.	Breather Filter - Gearbox. Filtration component used to protect the applicable oil, fuel, hydraulic or air system from contamination.
251	A2A50350501 (Type 1) / A2A50350502 (Type 2)	PB0000350501 (Type 1) / PB0000350502 (Type 2)	MBCSN70.0236	Installed on the exhaust gas and blade path temperature measuring positions of the turbine. UNEW drawing item No.: MBCSN70.0236.	Thermocouple. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.
252	A2A50350503	PB0000350503	MBCSN70.0237	Installed on the compressor discharge pressure measuring connection of the compressor casing. UNEW drawing item No.: MBCSN70.0237.	Pressure Transmitter - Compressor Discharge. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.
253	A2A50350504	PB0000350504	MBCSN30.0238	Installed on the bearing casings of the gas turbine, compressor end and turbine end, at the designated vibration-monitoring pickup position. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN30.0238.	Vibration Sensor - Bearing Housing. Bearing or bearing-support component used to support rotor alignment, control axial/radial movement, and maintain lubrication-system integrity.
254	A2A50350505	PB0000350505	MBCSN70.0239	Installed on the speed measuring position at the turbine shaft, opposite the speed pickup target. UNEW drawing item No.: MBCSN70.0239.	Speed Sensor - Turbine Shaft. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.
255	A2A50350506	PB0000350506	MBCSN70.0240	Installed on the combustion chamber, flame monitoring position of chambers A and B, at the designated ultraviolet flame-detector port. UNEW drawing "Combustion chamber shop assembly", Item No.: MBCSN70.0240.	Flame Detector. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.
256	A2A50350507	PB0000350507	MBCSN70.0241	Installed on the rotor axial position measuring station at the thrust bearing. UNEW drawing "Bearing Casing, Turbine", Item No.: MBCSN70.0241.	Proximity Probe - Rotor Axial Position. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.

No.	UNEW Part No.	UNEW PB No.	UNEW Drawing Item Location	Installation Location on the Machine and Drawing Reference	Description
257	A2A50350509	PB0000350509	MBCSN20.0002	Installed on the variable inlet guide vane actuator at the compressor inlet casing, on the IGV linkage/actuator feedback mechanism. UNEW drawing item No.: MBCSN20.0002.	Position Sensor - IGV Actuator. Compressor inlet guide vane assembly used to control inlet air angle and compressor operating margin during start-up, part-load and full-load operation.
258	A2A50350510	PB0000350510	MBCSN70.0243	Installed in the turbine protection cabinet of the unit control system, in the designated electronic control-system card slot. UNEW drawing item No.: MBCSN70.0243.	Control Card - Turbine Protection System. Instrumentation, monitoring or control component used for turbine protection, measurement, control feedback or operating diagnostics.
259	A2A50360601 (Type 1) / A2A50360602 (Type 2)	PB0000360601 (Type 1) / PB0000360602 (Type 2)	MBCSN40.0244	Installed on the flanged pipe joints of the fuel, air and oil systems of the gas turbine. UNEW drawing item No.: MBCSN40.0244.	Spiral Wound Gasket. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
260	A2A50360603	PB0000360603	MBCSN30.0245	Installed on the lube oil cooler of the lube oil supply unit, at the cooler cover/flange sealing interface. UNEW drawing item No.: MBCSN30.0245.	PTFE Sheet Gasket - Lube Oil Cooler. Sealing component used to control leakage, maintain pressure separation, or protect the applicable turbine, compressor, fuel, oil or casing interface.
261	A2A50360604 (Type 1) / A2A50360605 (Type 2)	PB0000360604 (Type 1) / PB0000360605 (Type 2)	MBCSN50.0246	Installed on the casing flange joints of the gas turbine, compressor and turbine sections. UNEW drawing item No.: MBCSN50.0246.	Stud Bolt. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
262	A2A50360606 (Type 1) / A2A50360607 (Type 2)	PB0000360606 (Type 1) / PB0000360607 (Type 2)	MBCSN50.0247	Installed on the casing flange joints of the gas turbine, compressor and turbine sections. UNEW drawing item No.: MBCSN50.0247.	Hex Nut. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
263	A2A50360608	PB0000360608	MBCSN50.0248	Installed on the exhaust casing horizontal and vertical joint bolting. UNEW drawing item No.: MBCSN50.0248.	Spring Washer M30 - Exhaust Casing. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
264	A2A50360609	PB0000360609	MBCSN50.0249	Installed at the blade locking and fastener securing positions of the turbine assembly, through drilled fasteners as secondary locking/safety wire. UNEW drawing item No.: MBCSN50.0249.	Locking Wire 0.8mm - Turbine Assembly. Mechanical fastening or locking hardware used to secure, locate or retain the applicable assembly during turbine operation and maintenance.
265	A2A50360610	PB0000360610	MBCSN90.0250	Applied to the casing, rotor and fastener threaded joints of the gas turbine during assembly. UNEW drawing item No.: MBCSN90.0250.	Anti-Seize Compound - High Temperature. Replacement component for the applicable V94.2 / SGT5-2000E gas turbine assembly.